



NOTES:

- PLACEMENT AND ORIENTATION OF THE PUSH BUTTON STATION IS CRITICAL. MOUNT THE BUTTON SO THAT THE FACE IS PARALLEL WITH THE ASSOCIATED CROSSWALK. SCREW IN POST TO A TIGHTENED POSITION BEFORE MOUNTING ACCESSIBLE PEDESTRIAN PUSH BUTTON UNIT TO THE POST.
- ORIENT ACCESS OPENING ON THE BREAKAWAY PEDESTAL DIRECTLY BELOW THE APS BUTTON.
- PLUMB THE PUSH BUTTON STATION WITH LEVELING SHIMS.
- BLIND THREADED INSERTS (RIVET NUT) MUST BE INSERTED USING MANUFACTURERS SPECIFIC INSTALLATION TOOL. NO OTHER METHOD OF INSTALLATION IS ACCEPTABLE.
- BLIND THREADED INSERTS SHALL BE ZINC PLATED STEEL WITH 1/4 - 20 UNC THREADS. INSERT SHALL BE SUITABLE FOR USE ON A MOUNTING SURFACE WALL THICKNESS OF .337".
- A.P.S. MOUNTING BOLTS SHALL BE 1/4 - 20 STAINLESS STEEL. APPLY BRUSH ON ANTI SEIZE COMPOUND TO BOLTS PRIOR TO ASSEMBLY.
- APPLY A BEAD OF 100% SILICONE SEALANT ALONG THE TOP OF THE PUSH BUTTON UNIT WHERE IT COMES IN CONTACT WITH THE 4" POST.
- THE REFLECTIVE SHEETING SHALL BE WHITE AT INTERSECTION CORNERS AND SHALL BE YELLOW WHEN USED IN CENTER MEDIANS.
FOR WHITE SHEETING USE 3M HIGH INTENSITY PRISMATIC SERIES 3930 OR EQUAL.
FOR YELLOW SEETING USE 3M HIGH INTENSITY PRISMATIC SERIES 3931 OR EQUAL.
- ANTI-SEIZE COMPOUND MUST BE USED ON ALL THREADED BOLTS WHEN INSTALLING PEDESTRIAN PUSH BUTTON STATIONS.

- ① THE PUSH BUTTON STATION FOUNDATION IS CONSTRUCTED PRIOR TO THE SIDEWALK INSTALLATION. USE 8" X 18" SONOTUBE TO INCREASE THE SIDEWALK THICKNESS TO 12" THICK (MIN.) TO PROVIDE FOR THE PUSH BUTTON STATION FOUNDATION.
- ② ALL JOINTS SHALL BE A MINIMUM OF 9" FROM THE CENTER OF THE PUSH BUTTON FOUNDATION
- ③ LOCATION OF PUSH BUTTON TO BE DETERMINED BY PROJECT ENGINEER IN THE FIELD.

	MINNEAPOLIS DEPARTMENT OF PUBLIC WORKS		POLE - SIGNAL PEDESTAL PUSH BUTTON	STANDARD PLATE NO. TRAF-1260-R4
	DRAWN: CLK	DATE: 9/14/15		
	APPROVED: DRP	DATE: 9/14/15		