


This message means: a previous ballot is waiting to be printed! If the message is still there after turning the printer off and on, call headquarters.





"READY TO PRINT" The printer is ready for the next voter

This message means: there are no ballots waiting to be printed.

